

ANALYSIS

Sebastien Incerti (CNRS, France)

based on material kindly provided by

I. Hrivnacova (CNRS) and A. Dotti (SLAC)

Contents

2

- Introduction on analysis
- Histograms
- Ntuples
- UI Commands for analysis

3

Introduction

Introduction

4

- Geant4 **does not provide** a complete analysis subsystem
 - Our user community is too **heterogeneous**
 - Each user group has its own requirements and a favorite tool
 - e.g. **ROOT** in HEP, what is yours ?

- Typical simulation output consists of
 - **ntuples-like** tables (row: event, column: quantity)
 - **histograms**

Status of g4analysis

5

- Analysis category in Geant4 since December 2011
 - ▣ Before the analysis code in Geant4 examples used external tools (based on [AIDA](#) = Abstract Interfaces for Data Analysis) that had to be linked with Geant4 to produce histograms or ntuples

- Area of **new developments** and improvements: more features are added in each release
 - ▣ Example from the latest release: better MPI (Message Passing Interface) support

- Based on [g4tools](#) from inlib/exlib developed by G. Barrand (LAL, France)
 - ▣ <http://inexlib.lal.in2p3.fr>
 - ▣ “**Pure header code**” - all code is inlined : can be installed on iOS, Android, UNIXes, Windows...

- Provides code to **write histograms** and “**flat ntuples**” in several formats: **ROOT**, **XML AIDA format**, **CSV for ntuples**

Status of g4analysis

6

- It includes a manager (**G4AnalysisManager**)
 - ▣ Handles output file(s) creation
 - ▣ Owns and handles histograms and ntuples
- It provides
 - ▣ Uniform interface
 - Hides the differences according to a selected technology (root, XML, HBOOK, CSV) from the user
 - ▣ Higher level management of g4tools objects (file, histograms, ntuples)
 - Memory management
 - Access to histograms, ntuple columns via indexes
- Integration in the Geant4 framework
 - ▣ Interactive commands, units
- It is **thread-safe** and provides **automatic summing** of histograms

7

Histograms

Using Geant4 Analysis

8

□ 3 basic steps

1. - Create **G4AnalysisManager**
 - Book (create) your **histograms, ntuples**
 - Open a file
2. Fill values in histograms, ntuples
3. Write & close file

Using Geant4 Analysis

9

□ The few basic steps in detail...

1. Create `G4AnalysisManager`
Open an output file
Book (create) your `histograms, ntuples`
in `RunAction BeginOfRunAction()`
2. Fill values in histograms, ntuples
anywhere during event processing,
e.g. in `EventAction`
`EndOfEventAction()`
in `RunAction BeginOfRunAction()`
3. Write & close file
in `RunAction EndOfRunAction()`

Note: performing the steps in the suggested classes & methods is not mandatory, but it guarantees correct functioning in `multi-threaded mode`

Selection of **output type**

10

- For simplicity of use, **G4AnalysisManager** provides a complete access to all interfaced methods for all output formats: **ROOT, CSV, AIDA XML**
 - though it is implemented via a more complex design
 - the real type is different for each output type:
G4RootAnalysisManager, G4CsvAnalysisManager, G4XmlAnalysisManager
- The generic types are defined in dedicated header files for each output type:
 - **g4root.hh, g4csv.hh, g4xml.hh**
 - using **namespaces** and **typedefs**
- It is recommended to **add the selected include in an extra header file MyAnalysis.hh** and **include this header file in all classes** which use g4analysis

MyAnalysis.hh

```
#ifndef MyAnalysis_h
#define MyAnalysis_h 1

#include "g4root.hh"
// #include "g4csv.hh"
// #include "g4xml.hh"
#endif
```

1) Step 1: creation

11

MyRunAction.cc

```
#include "MyAnalysis.hh"

void MyRunAction::BeginOfRunAction(const G4Run* run)
{
    // Create analysis manager
    G4AnalysisManager* analysisManager = G4AnalysisManager::Instance();
    analysisManager->SetVerboseLevel(1);

    // Open an output file
    analysisManager->OpenFile("MyApplication");

    // Create histograms
    analysisManager->CreateH1("Edep", "Energy deposit", 100, 0., 800*MeV);
    analysisManager->CreateH1("Tlen", "Track length", 100, 0., 100*mm);
}
```

2) Step 2: filling

12

- Example of filling 2 one-dimensional histograms

MyEventAction.cc

```
#include "MyAnalysis.hh"

void MyEventAction::EndOfEventAction(const G4Event* event)
{
    // Get analysis manager
    G4AnalysisManager* analysisManager = G4AnalysisManager::Instance();

    // Fill histograms
    analysisManager->FillH1(0, fEdep);
    analysisManager->FillH1(1, fTrackLength);
}
```

3) Step 3: write & close

13

- Example of writing & closing the output file

MyRunAction.cc

```
#include "MyAnalysis.hh"

void MyRunAction::EndOfRunAction(const G4Run* run)
{
    // Get analysis manager
    G4AnalysisManager* analysisManager = G4AnalysisManager::Instance();

    // Write and close the output file
    analysisManager->Write();
    analysisManager->CloseFile();
}
```

More on histograms

14

- 1D, 2D, 3D histograms and 1D, 2D profile histograms available
- Histogram **identifiers**
 - The histogram **ID** is **automatically generated** when a histogram is created by `G4AnalysisManager::CreateH1()`, and its value is returned from this function
 - Note: the histogram names have no relation to the histogram ID which is used at filling
 - The **default start value 0** can be changed (eg. to 1) with:
`G4AnalysisManager::SetFirstHistId(G4int)`
 - The 1D, 2D and 3D histograms IDs are defined independently
- Histogram **objects**
 - It is also possible to **access directly a histogram** by
`G4AnalysisManager::GetH1(G4int id)`
The concrete histogram type is hidden behind a selected namespace

```
G4cout << "Print histograms statistic \n" << G4endl;  
G4cout << " EAbs : mean = " << analysisManager->GetH1(1)->mean()  
      << " rms = " << analysisManager->GetH1(1)->rms() << G4endl;
```

Histogram options

15

- Properties, additional to those defined in g4tools, can be added to histograms via [G4AnalysisManager](#)
 - ▣ **Unit** : if defined, all filled values are automatically converted to this defined unit
 - ▣ **Function** : if defined, the function is automatically executed on the filled values (can be **log**, **log10**, **exp**)
 - When a histogram is defined with both unit and function, then the unit is applied first
 - ▣ **Binning scheme** : users can define a non-equidistant binning scheme (passing a vector of bin edges)
 - UI command only for lin/log scheme
 - ▣ **ASCII option** : if activated the histogram is also printed in an ASCII file when [G4AnalysisManager::Write\(\)](#) function is called
 - ▣ See [/analysis/h1 /set](#) UI commands

16

Ntuples

1) Step 1: creation

17

- Example of creating an ntuple

MyRunAction.cc

```
void MyRunAction::BeginOfRunAction(const G4Run* run)
{
    // Create analysis manager
    G4AnalysisManager* analysisManager = G4AnalysisManager::Instance();
    analysisManager->SetVerboseLevel(1);

    // Open an output file
    analysisManager->OpenFile("MyApplication");

    // Creation of ntuple
    analysisManager->CreateNtuple("MyNtuple", "Edep and TrackLength");
    analysisManager->CreateNtupleDColumn("Eabs");
    analysisManager->CreateNtupleDColumn("Labs");
    analysisManager->FinishNtuple();
}
```

2) Step 2: filling

18

- Example of filling an ntuple

MyEventAction.cc

```
void MyEventAction::EndOfEventAction(const G4Event* event)
{
    // Get analysis manager
    G4AnalysisManager* analysisManager = G4AnalysisManager::Instance();

    // Fill ntuple
    analysisManager->FillNtupleDColumn(0, fEnergyAbs);
    analysisManager->FillNtupleDColumn(1, fTrackLAbs);
    analysisManager->AddNtupleRow();
}
```

3) Step 3: write & close

19

- Example of writing & closing the output file

MyRunAction.cc

```
#include "MyAnalysis.hh"

void MyRunAction::EndOfRunAction(const G4Run* run)
{
    // Get analysis manager
    G4AnalysisManager* analysisManager = G4AnalysisManager::Instance();

    // Write and close the output file
    analysisManager->Write();
    analysisManager->CloseFile();
}
```

More on ntuples

20

- **Ntuple and Ntuple Column identifiers**
 - **Automatically** generated when the ntuple or ntuple column is created by `G4AnalysisManager::CreateNtuple()` or `G4AnalysisManager::CreateNtupleTColumn()` and its value is returned from this function.
 - The **default start value 0** can be changed with the `G4AnalysisManager::SetFirstNtupleId(G4int)` and `G4AnalysisManager::SetFirstNtupleColumnId(G4int)` methods.
 - In a similar way as for histogram ID

- The ntuple **column ID** is not specific to the column type: available column types:
 - integer (I), float (F), double (D), string (S)
 - `std::vector` of integer (I), float (F), double (D) types

21

UI commands

Analysis **UI** commands (1 / 3): **options** and **output file** handling

22

□ General options

```
# Set verbose level  
/analysis/verbose level  
# Set activation option  
/analysis/setActivation true|false
```

□ Handling output files and general options

```
# Set name for the histograms and ntuple file  
/analysis/setFileName name  
# Set name for the histograms/ntuple directory  
/analysis/setHistoDirName name  
/analysis/setNtupleDirName name
```

UI commands (2/3)

23

- Commands to create or define 1D histogram

```
# Create 1D histogram
/analysis/h1/create name title [nbin min max] [unit] [fcn] [binscheme]

# Set histogram parameters
/analysis/h1/set id nbin min max [unit] [fcn] [binscheme]
```

- Example of a macro `gammaSpectrum.mac` in `TestEm5` example ([examples/extended/electromagnetic/TestEm5/gammaSpectrum.mac](#))

```
/analysis/setFileName gammaSpectrum
/analysis/h1/set 3 200 0.01 10 MeV #gamma: energy at vertex
/analysis/h1/set 5 200 0.01 10 MeV log10 #gamma: energy at vertex (log10)
/analysis/h1/set 20 200 0 6 MeV #gamma: energy at exit
/analysis/h1/set 40 200 0 6 MeV #gamma: energy at back
```

- Analogous commands are available for 2D and 3D histograms and 1D and 2D profiles

UI commands (3/3)

24

□ For 1D histograms control

```
# Activate printing 1D histogram on ASCII file
/analysis/h1/setAscii id true|false
# Set title for the 1D histogram
/analysis/h1/setTitle id title
# Set x-axis, y-axis title for the 1D histogram
/analysis/h1/setXaxis id title
/analysis/h1/setYaxis id title
# Set activation for the id 1D histogram
/analysis/h1/setActivation id true|false
# Set activation to all 1D histograms
/analysis/h1/setActivationToAll true|false
```

- The same sets of commands are available for 2D and 3D histograms and 1D and 2D profiles, under h2, h3, p1 and p2 directories

More: **batch** graphics (1 / 3)

25

- Since Version 10.2
- Users can activate plotting of selected histograms and profiles using **G4AnalysisManager** methods

```
// Activate plotting of 1D histogram  
analysisManager->SetH1Plotting(id, true);  
// etc for H2, H3, P1, P2
```

- Or via UI command

```
/analysis/h1/setPlotting id true|false  
/analysis/h1/setPlottingToAll true|false  
## etc for h2, h3, p1, p2
```

- The selected objects will be plotted in a single postscript file with the page size fixed to A4 format

More: **output** files (2/3)

26

Depending on selected file format, multiple output files can be produced

- **ROOT**
 - ▣ All histograms, profiles and ntuples are written in one file
- **XML (AIDA)**
 - ▣ The histograms and profiles are written in one file, and each ntuple is written in a separate file
- **CSV (comma-separated values)**
 - ▣ Each histogram, profile and ntuple are written in a separate file

File names are generated automatically

fileName[_objectName].ext where **ext = xml, csv**

More: plotting **style** (3/3)

27

- Set plotting style

```
/analysis/plot/setStyle styleName
```

- **ROOT_default** (default), **hippodraw**: high resolution fonts
- **inlib_default** : low resolution fonts
- High resolution fonts are available only if Geant4 libraries are built with the support for Freetype font rendering

- Set the page layout


```
/analysis/plot/setLayout columns rows
```

- The number columns and the number of rows in a page
- The maximum number of plots is limited according to selected style

- A powerful analysis tool from CERN
 - ▣ Installed on your virtual machine
- Start session with `root`, then open a browser with:
`root [0] new TBrowser`

File generated
In Geant4
simulation

Selected H1
is automatically
drawn in the
canvas



Geant4 examples

29

- In [examples/extended/analysis](#), 3 examples to demonstrate how to make histograms and ntuples
 - [AnaEx01](#) – use of Geant4 analysis tools
 - [AnaEx02](#) – use of ROOT classes, requires linking with Root libraries
 - [AnaEx03](#) – use of AIDA interface classes, requires linking with an AIDA compliant tool, eg. OpenScientist

- http://geant4.web.cern.ch/geant4/UserDocumentation/Doxygen/examples_doc/html/Examples_analysis.html

Summary

30

- Geant4 provides a lightweight analysis tools as part of distribution
- Can handle **histograms** (1D, 2D, profiles) and **ntuples**
- Variety of **UI commands**
- Variety of **output formats**
- Compatible with **MT**
 - ▣ Histogram and ntuple merging
- The Geant4 analysis is now used in all basic, extended and most of advanced examples
- Users can also choose to use an external package and link their application against its libraries